



OPERATING INSTRUCTIONS

ROLLING DOOR OPERATORS

1. CONTENTS

1. Contents	3
2. General instructions	3
3. Safety-related regulations	4
4. Safety instructions	4
5. Mounting.....	5
6. Anti-Drop Safeguard.....	6
7. Initial operation	6
8. Technical data	12
9. Dimensions.....	12
10. Drawings.....	13
11. Maintenance	14
12. Transport, Storage, Disposal.....	14
13. Service, Spare parts, Accessories	14
14. Declaration of conformity.....	15
15. Annex	16

2. GENERAL INSTRUCTIONS

2.1 Original operating instructions

This manual is the original manual.

- Copyright protection: any reproduction is permitted only with approval of the manufacturer.
- Subject to alterations in the interest of technical progress.
- All dimensions given in mm. The diagrams in this manual are not to scale.

2.2 Intended use

The operator series TDA2, TDA4 and TDA6 are designed exclusively for opening and closing doors (such as rolling doors or rolling grilles) which have to be secured against falling.

For other applications of the operators, the manufacturer must be consulted.

2.3 Warranty

The function and safety of the equipment is only guaranteed if the warning and safety instructions included in these operating instructions are adhered to.

The manufacturer is not liable for injury to persons or damage to property if these occur as a result of the warnings and safety advice being disregarded.

The CE declaration and the warranty will void if components are changed.

Only original spare parts and by the manufacturer approved accessories shall be used. These parts are used to maintain the quality and safety of the machine. Changes are only permitted after consultation with the manufacturer.

2.4 Target group

Only qualified and trained specialists are permitted to mount the operator and perform mechanical maintenance.

Only qualified and trained electricians may connect the operator and carry out the electrical maintenance.

Qualified and trained people have knowledge of general and specific safety and accident prevention regulations, the relevant regulations and standards, training in the use and maintenance of adequate safety equipment, as well as the ability to recognize hazards associated with their work.

2.5 Key to symbols



DANGER !

Indicates a hazard with a high level of risk which, if not avoided, will result in death or serious injury.



WARNING !

Indicates a hazard with a medium level of risk which, if not avoided, could result in death or serious injury.



CAUTION !

Indicates a hazard with a low level of risk which, if not avoided, could result in minor or moderate injury.

NOTICE !

Indicates an imminent danger of damage or destruction.

INFORMATION !

Reference to separate documents which must be complied with.

3. SAFETY-RELATED REGULATIONS

For connecting, programming and servicing, the following regulations must be observed (the list is not exhaustive)!

Construction product standards:

- EN 13241-1
- EN 12445
- EN 12453
- EN 12635
- EN 12978

Electromagnetic compatibility (EMC):

- EN 55014-1
- EN 61000-3-2
- EN 61000-3-3
- EN 61000-6-2
- EN 61000-6-3

Machinery Directive

- EN 60204-1
- EN 12100-1

Local protective regulations must be complied with.

4. SAFETY INSTRUCTIONS



DANGER !

Failure to observe the instructions in this document can result in mortal danger!



DANGER !

Risk of death by electric shock!

- When installing the operator, when opening housings and work on electrical equipment, the operator has to be disconnected from the power.
- Observe the local safety regulations.

NOTICE !

To avoid damage to the operator and at the door, the drive must be mounted only if:

- the drive is undamaged,
- the ambient temperature is -20°C to $+60^{\circ}\text{C}$,
- the installation site altitude does not exceed 1,000 m above sea level.
- The use of the operator, as well as the standard cable is only allowed indoors.
- For outdoor installation must be consulted with the manufacturer.



WARNING !

- Make sure that children can not access the door control or the hand-held transmitter.
- Ensure, before moving the door, that no persons or objects within range of the door.
- Test all existing emergency command devices.
- Pay attention to possible crushing and shearing points on the door system.
- Never reach into a running gate, into the guide rail or moving parts.

INFORMATION !

For drives with fixed connection a main switch with appropriate building main fuse must be provided.



WARNING !

Before installation, ensure that:

- the operator is installed with the intended covers or guards,
- all seals are correctly and
- all glands and screws are tightened correctly.

5. MOUNTING

5.1 Preparation

- Check that the delivery is complete.
- Check if all accessories for your installation situation are present (e.g. bracket).
- Check if the system has a suitable mains connection and a mains switch.
- Remove all unnecessary components from the door
- Remove all devices, which are not required after installation of the drive system.
- Before installation, ensure that the operator is not blocked,
- Before installation, ensure that the operator has been newly prepared after a lengthy storage period,
- Before installation, ensure that no other sources of danger are present,
- Before installation, ensure that the installation site has been cordoned off over a wide area.




DANGER !


All components must be designed in relation to the construction and the ground for the loads during tripping of the safety catch device.

5.2 Mounting the Operator

- Install the torque bracket
- Insert the feather key into the shaft
- The shaft end is greased before fitting the drive
- When using collars, slide the collar onto the shaft



- Secure the feather key against sliding
- Connect the drive to the shaft
- Attach the drive to the bracket
- Slide the counter bearing onto the shaft
- Attach the counter bearing to the bracket
- The brackets must be mounted so that the shaft is in the horizontal
- The fixation against axial displacement of the shaft is made on the opposite side at counter bearing, by means of a screw or with collars on both sides



NOTICE !

- To avoid damage to the operator and to the door, the operator must be mounted on a bracket with a pendulum foot or a torque support bracket so that it is vibration dampened.
- When mounting the operator do not carry or pull at the cable.



DANGER !

With a continuous shaft groove the feather key has to be secured against moving.



CAUTION !

For operators with weights greater than 20 kg additional aids shall be used, such as hooks or ropes for securing and lifting. On the drives corresponding eyes are provided.

INFORMATION !

The relevant instructions for the door must be observed when fitting the operator to the door.

6. ANTI-DROP SAFEGUARD

In accordance with the EN 12604 all TDA-operators are equipped with an integrated locking device, which works in both directions.


The locking device is entrained load-free and wear-free. If the drive unit fails, the locking device is automatically triggered. The load moved by the operator is then smoothly brought to a standstill in the position concerned.

The power transmission between the motor and the door shaft is interrupted after the drive unit fails. The operator must be replaced.

The anti-drop safeguard device is distinguished by the following features:

- Protection against worm shaft and worm gear failure
- Independent of the rotational speed
- Independent of the direction of rotation
- Can be mounted in any position
- Unsusceptible to vibrations
- Maintenance-free
- Self-controlling
- Excellent damping properties when device is triggered

6.1 Function



In case of exceeding wear the teeth of the brass worm wheel (B) may collapse and allow the wheel to turn underneath the steel worm shaft (A). The pilot wheel (C) remains unaffected, due to the relative rotation of the two wheels a set of hardened lock-bolts (D) are released and will immediately and permanently block the gearbox.

Nebenstehende Maximalwerte dürfen auch bei frequenzgeregeltem Betrieb nicht überschritten werden The values in this table may not be exceeded even in frequency controlled operation	max. Betriebsdrehzahl max. Operating Speed	max. zul. Drehmoment max. Torque
TOR-FV 5/083	100 min ⁻¹	200 Nm
	200 min ⁻¹	100 Nm
TOR-FV 7/119	95 min ⁻¹	750 Nm
	210 min ⁻¹	300 Nm
TOR-FV 6/111	30 min ⁻¹	1.554 Nm
	120 min ⁻¹	1.118 Nm

7. INITIAL OPERATION

Power-operated doors shall be audited at least annually by a trained person, before first use and as required (with written proof).

The operator of the door system shall be trained after initial operation.

Before installation, ensure that the direction of rotation of the gear motor is correct, and all protective devices are active.

NOTICE !

To avoid damage to the drive, the following points must be observed:

- The types of cable and their diameters must be selected according to current regulations.
- The nominal currents and the type of connection must correspond to those on the motor type plate.
- The drive details must agree with the connected loads.



DANGER !

Danger of fatal electric shock!

Before commencing cabling works, you **MUST** disconnect the drive system from the main supply. Ensure that the electricity supply remains disconnected throughout the cabling works.

NOTICE !

When mounting the motor cables to ensure that the individual wires are inserted deep enough and the screws are tightened so that a firm connection is made. This connection can be checked by pulling the cables.


7.1 Connection to the control unit

The operator is factory wired to the control unit. If this is not the case, proceed as follows:


- Remove the cover from the operator.
- Run the cable gland of the cable into the corresponding fitting.
- Connect the motor cable to the plug, the plug is polarized.
- Connect the limit switch:
AWG: connect plug
Mechanical limit switch: connect according to diagram
- Attach the cover back on the operator.

Connection

Connection to cable set for mechanical limit switches:



Connection to cable set for electronic limit switches:



NOTICE !


When used with frequency converter control units, only shielded cables shall be used.

7.2 Mechanical limit switch


Cam (from outside in)	ME 6 (6 cams)
RED	Safety limit switch open
GREEN	Limit switch open
GREEN	Add. Limit switch 1
WHITE	Limit switch close
RED	Safety limit switch close
WHITE	Add. Limit switch 2

7.3 Connection

Operators series TDA 2:



Operators series TDA 4 or TDA 6 (PCB):



7.4 Setting the end positions: mechanical limit switch

For the adjustment of the cam an Allen key size 2.5 is required (included with the drive). The cam is fixed on the correct switch position using the locking screw after positioning (rough setting). Fine adjustment is possible via the precision set screw.

To set the limit switch, the operator must be ready for operation, completely mechanically fitted and electrically connected.

Before the first activation of the operator the door should be in a center position to ensure there is sufficient travel in both directions when starting.

On actuating the button OPEN, the door must open. Otherwise the two phases L1 and L2 have to be exchanged.

To do this, control and drive must be disconnected from the main supply.

Setting the CLOSED end position

- Bring the door in the CLOSED end position.
- Set the cam so that the CLOSED limit switch is actuated.
- Tighten the locking screw.
- The Safety limit switch CLOSED must be set so that it switches immediately when the limit switch CLOSED is passed over.
- Adjust the safety limit switch CLOSED.

Setting the OPEN end position

- Bring the door in the OPEN end position.
- Set the cam so that the OPEN limit switch is actuated.
- Tighten the locking screw.
- The Safety limit switch OPEN must be set so that it switches immediately when the limit switch OPEN is passed over.
- Adjust the safety limit switch OPEN.

Additional limit switches:

- Bring the door to the desired position from the desired direction (e.g. partial open position from the position CLOSED).


- Set the switch cam so that the additional limit switch is actuated.
- Tighten the locking screw.

Correct the end positions

With the fine adjustment screw a readjustment of the respective end position is possible.

Check of end positions

Check if the end positions are set correctly and if the operator stops in the corresponding end position.




7.5 Connection of the electronic limit switch

The electronic (digital) limit switch is an absolute value encoder.

It is connected via an RS485 interface to the control unit.

The encoder has a 6-pin connector on the serial interface, which is connected to the control unit.

The safety switches of the operator are connected to the terminals 7 - 12. Unused terminals must be equipped with a wire bridge.



Pin	Assignment	Color
1	Safety chain in	Yellow
2	RS 485 B	Green
3	0 VDC	White
4	RS 485 A	Pink
5	Safety chain out	Grey
6	7 ... 18 VDC	Brown



WARNING !

- Accidental venting of the brake must be rendered impossible by preventive measures at the installation site.

INFORMATION !


- For safety reasons, brakes in doors without a weight counterbalance must only be vented in the closed door position for testing purposes.
- If the door is moved beyond the CLOSED or OPEN end positions, the operator can no longer be activated electrically.

7.6 Setting the end positions: electronic limit switch

Please refer to the control unit operating manual for instructions on setting the end positions.

7.7 Connection of the brake / brake rectifier

Operators TDA4 and TDA6 > 600Nm are equipped with a DC-Brake. The brake rectifier is integrated in the drive and pre-wired at the factory. For the connection a neutral conductor is required.



7.8 Emergency operation

During maintenance works or in the case of an electrical fault, the door can be moved towards the OPEN or CLOSED positions with the help of the emergency operation equipment.



WARNING !


Improper use may result in serious injury!

- Emergency operation must only be carried out when the motor is stationary.
- The system must be disconnected from the power supply during emergency operation.
- Emergency operation must only be carried out from a safe standing position.
- Operators with a spring brake must be actuated against the closed brake when opening or closing the door.

7.9 Hand Crank

A insertion aid at the housing of emergency crank handle facilitates the insertion of the crank.

1. Release the emergency hand crank from its fixing.
2. Insert the hand crank with slight pressure and a little turning into the operator as far as it will go.
3. A micro switch is actuated and interrupts the energy supply to the motor via the safety circuit in the control system.
4. Open or close the door using the hand crank.
5. If the crank is removed, the micro switch automatically releases the control system. The door can be operated electrically again.




7.10 Hand chain

By pulling the release lever, the coiler shaft of the hand chain system is shifted and thus switches between motor - and manual operation.

When switching to manual mode a micro switch is actuated and interrupts the safety circuit. No motor operation is possible.

1. Red handle - HAND (system coupled):
Switching to manual mode
(the operating force is max. 390 N)
2. Open or close the door using the hand chain.
3. Green handle - MOTOR (system decoupled)
Switching to motor operation
(the operating force is max. 390 N)
4. The door can be operated again electrically.



system decoupled
(motor operation)

system coupled
(manual operation)

Depending on the torque of the drive, the chain system is designed with different sized wheels and with different ratios:

Torque	Ratio	Ø Wheel
up to 180 Nm	1:1	165 mm
up to 300 Nm	1:1	200 mm
up to 450 Nm	2:1	165 mm
up to 550/650 Nm	2:1	200 mm


7.11 Extending or shortening the chain

The coil is joined via one or two coupling links (marked by color yellow).

It can be opened at the coupling link and can be extended with a piece of chain and another coupling link.

When shortening, the respective part is to be separated from the coil chain using a bolt cutter. The coupling links must be carefully bent together.

When making changes to the coil chain, make sure that the chain is not twisted when mounted.



7.12 Rotate the hand chain system

The emergency chain system can be rotated by 180° so that the coil wheel is on the other side.

To do this, the 4 fastening screws are unscrewed, the housing is rotated by 180 ° and then re-tightened (M=7Nm).

8. TECHNICAL DATA

	Anlauf-Drehmoment Starting Torque	Nenn-Drehmoment Nominal Torque	Abtriebsdrehzahl Output Speed	Zulassungs Nummer TOR-FV.. Approval No. TOR-FV...	Endschalterbereich ²⁾ Limit capacity ²⁾	Hohlwellen Durchmesser ³⁾ Hollowshaft Diameter ³⁾	Betriebsspannung (50Hz) Operating Voltage (50 Hz)	Motorleistung Engine Output	Motorlebensdauer Duty Cycle Engine	Betätigungen pro Stunde Operating cycles per hour	Nenn - Strom bei 230 / 400V Nominal Current at 230 / 400 V	siehe Maßbild / Länge L ₁ see Drawing / Length L ₁	Art der Notbetätigung Type of manual operation	Schutzart Protection Category	Gewicht / Weight
Antriebsart Operator Type	M _A [Nm]	M _N [Nm]	n ₂ [min ⁻¹]	TOR-FV	i _{st}	D [mm]	U [V]	P [kW]	S3 [%]		I _N [A]	L ₁ [mm]		IP	G [kg]
TDA2-140.18	140	115	18	5/083	15	30	3~230 3~400	0,55	40	20	3,54 2,0	A/264	KU/ KE	54	13
TDA2-180.14	180	160	14	5/083	15	30	3~230 3~400	0,50	40	15	3,5 2,0	A/277 ⁴⁾	KU/ KE	54	15
TDA4-220.14	220	180	14	7/119	10	30	3~230 3~400	0,75	40	20	5 2,0	B/328	KU/ KE	54	22
TDA4-300.14	300	250	14	7/119	10	30	3~230 3~400	1,0	40	20	5 2,9	B/328	KU/ KE	54	25
TDA4-450.14	450	430	14	7/119	10	40	3~230 3~400	1,5	40	20	6,4 3,7	B/341	KU/ KE	54	30
TDA4-550.11	550	450	11	7/119	10	40	3~230 3~400	1,5	40	20	8,7 5,0	B/391	KU/ KE	54	30
TDA4-650.10 ¹⁾	650	550	10	7/119	10	40	3~230 3~400	1,5	40	20	7,8 4,5	C/446	KU/ KE	54	35
TDA6-750.10 ¹⁾	750	650	10	6/111	10	55	3~230 3~400	1,5	40	20	7,6 4,4	D/386	KU	54	52
TDA6-1000.10 ¹⁾	1000	850	10	6/111	10	55	3~230 3~400	2,2	40	20	13 7,5	D/440	KU	54	52
TDA6-1400.9 ¹⁾	1400	1250	9	6/111	10	55	3~230 3~400	2,2	40	20	13 7,5	E/542	KU	54	58

¹⁾ Operator is equipped with DC-brake, neutral connection is required.

²⁾ Limit ratio 20:1 e.g. 40:1 available on request .

³⁾ All hollow shaft fitting H8, Keyway acc. to DIN 6885; Ø 30 = 8x7, Ø 40 = 12x8, Ø 55 = 16x10

⁴⁾ Enlarged width 128 mm instead of 110 mm .

9. DIMENSIONS

The following illustrations show all relevant dimensions of our operator series.

Refer to the table of technical data for the assignment of the sketches and for dimension L 1 .


Dimensions of Manual Override

	Kurbellänge Crank Length	Kurbel Radius Crank-Radius	Länge Kettentrieb Legth Chaindrive	Breite Kettenseitig Width Chain-Side	Breite Kupplungsseitig Width Clutch-Side
	L _K [mm]	R _K [mm]	L _C [mm]	B ₁ [mm]	B ₂ [mm]
TDA2	230	80	125	110	95
TDA4	230	185	165	120	95
TDA6	340	220	_1)	_1)	_1)


¹⁾ Handchain not available

10. DRAWINGS


Maßbild „A“ · Drawing „A“




Maßbild „B“ · Drawing „B“




Maßbild „C“ · Drawing „C“




Maßbild „D“ · Drawing „D“



Maßbild „E“ · Drawing „E“



Maßbild „Notbetätigung“ · „Manual Override“



11. MAINTENANCE / ANNUAL INSPECTION



DANGER !

Danger of fatal electric shock!

- For maintenance of the operator, when opening housings and work on electrical equipment, the operator is disconnected from the main power.
- Observe the local safety regulations.

NOTICE !

- Only original spare parts and approved accessories shall be used
- Changes are only permitted after consultation with the manufacturer.

INFORMATION !

- The maintenance of power-operated windows, doors and gates must be performed only by authorized persons who are familiar with the relevant maintenance and the national and local regulations.

11.1 Gear unit

The gear unit has lifetime lubrication and is maintenance-free. The hollow shaft must be kept rust-free. Check for noise and oil leakage.

11.2 Motor

The motor is maintenance free.

11.3 Fixtures

All fastening screws must be checked for tightness and proper condition.

11.4 Brake

Check the brake for functionality.

11.5 Cabling

Check power cord and cables regularly for damage and insulation failure.

12. Transport, Storage, Disposal

The drive has been fully assembled at the factory, ready wired, tested and packaged.

To avoid damage, the transport or storage in the original packaging or equivalent make.

For the disposal of the national regulations must be observed.

INFORMATION !

Attention! The gearbox contains oil. A proper disposal must be ensured.

13. Service, Spare Parts, Accessories

Only original spare parts and approved accessories may be used. The use of non-original spare parts and accessories may affect the functionality and the safety of the system. For damages incurred thereby, any liability and warranty is excluded.

In the case of malfunctions which you can not easily remedy yourself, please consult a specialist from the manufacturer of the door system or another specialist company.

14. DECLARATION OF CONFORMITY

We hereby declare that the products described below:

Rolling door operators of the model ranges TDA2, TDA4 and TDA6

are in conformity with the essential requirements of the Machinery Directive 2006/42/EC:

In addition, the partly completed machinery is in conformity with

the Construction Products Directive 89/106/EC

the Electromagnetic Compatibility Directive 2004/108/EC

the Low Voltage Directive 2006/95/EC

The following standards were applied:

EN 60204-1

EN 12100-1

DIN EN 12453

DIN EN 12604

EN 61000-6-2

EN 61000-6-3

EN 60335-1

EN 60335-2-103

Manufacturer and technical documentation management

ETME GmbH
Flohrstr. 33
D-13507 Berlin

The relevant technical documentation is compiled in accordance with Annex VII(B) of the Machinery Directive 2006/42/EC. We undertake to transmit, in response to a reasoned request by the market surveillance authorities, this documentation in electronic form within a reasonable period of time.

The machinery is incomplete and must not be put into service until the machinery into which the partly completed machinery is to be incorporated has been declared in conformity with the provisions of the Machinery Directive 2006/42/EC.

Place, Date

Berlin, 01.01.2013

Manufacturer's signature

A handwritten signature in black ink, appearing to read 'Konrad Machill'.

Konrad Machill
Technical Director

15. ANNEX – STAR / DELTA CONNECTION

The operator in the standard version is suitable as three-phase motor for 230V/400V operation.

By rewiring is possible to switch the operator from the factory star connection for 3 ~ 400V to the delta connection for 3 ~ 230V.

The winding ends have to be rewired as shown below:



DANGER !

Danger of fatal electric shock!

- Before commencing cabling works, you MUST disconnect the drive system from the mains supply.
- Ensure that the electricity supply remains disconnected throughout the cabling works.


NOTICE !

If the motor is wired to delta (3 ~ 230) ensure, that the control unit and the mains power supply are adapted to this voltage!


When reconnecting the motor cable to make sure that the individual lines are inserted deep enough into the connector and the screws are tightened properly (torque max. 0.5 Nm). The connection can be checked by gently pulling at the cable.

All IEC 80 and IEC 90 stators until the end of 2012

Star 3~400V




Delta 3~230V




All IEC 80 and IEC 90 stators from 2013
and all IEC 63 stators

Star 3~400V



Delta 3~230V





ETME PRODUKTE

- ▶ Rolltorantriebe
- ▶ Kettenradantriebe
- ▶ Sektionaltorantriebe
- ▶ Schnelllauforantriebe
- ▶ Schiebetorantriebe
- ▶ Steuerungen
- ▶ Sicherheitssysteme
- ▶ Zubehör



ETME PRODUCTS

- ▶ Operators for Roller Shutters
- ▶ Chain Wheel Operators
- ▶ Operators for Sectional Doors
- ▶ High-Speed Doors
- ▶ Operators for Sliding Gates
- ▶ Controls
- ▶ Safety Systems
- ▶ Accessories